

Clarity - No mapping for the Unicode character exits

Problem:

No mapping for the Unicode characters exits

Solution:

Steps:

1. Exit clarity
2. Go to clarity folder > settings (by default install folder is - C:\Program Files\Clarity\Settings or C:\Program Files (x86)\Clarity\Settings)
3. There are several folders here for each user. Rename the folder for user which has problem and run Clarity.